


///ATOM MODEL 205 LAWN EDGER PARTS LIST

KEY #	PART #	DESCRIPTION
1	40650	Screw M5 x 36mm
2	40652	Nut Nyloc 5mm
3	40835	Bearing 31x10x12mm
4	40838	Hex Screw 6mm x 19mm
5	40906	"O" Ring
6	42111	Seals nylon od27.2 x 12.70
7	42112	Felt Seal
8	43452	Adjusting arm spring
10	43105	Cross blade set (formed & straight)
11	44302	Adjust arm bolt & pin
12	43108	Bearing with Seal 37x12x12
13	43109	Blade cover support
14	43110	Blade cover
15	43112	Blade drum
16	43114	Blade shaft drive
17	43115	Blade washer small
18	43116	Blade washer large
19	43122	Crown gear L/E
20	43125	Spacer 15.5mm
21	43127	Warning label hot motor
22	43128	Warning label blade cover
23	43133	Warning label handle
26	44308	Grass shield limiter Pro AV2
28	43155	Main body shield
30	43163	Flange nut 3/8 UNC
31	43172	Nut M12 x 1.75
32	43173	Nut M12 x 1.75
33	43176	Pinion L.E. Long (25.4mm)
34	43179	Bearing screw M5 x 39
36	43198	Trigger comp. Spring
37	43199	Trigger Spring, Small
41	44307	Wheel axle tube spacer 94.35mm
42	44301	Wheel support arm (AV2)
43	44304	Wheel support axle bolt 3/8x5.5
45	43218	Washer Fiat 9 77x19.05x1.6
47	43288	Throttle trigger(hook)
48	43292	Throttle interlock
49	43294	Switch slide

KEY #	PART #	DESCRIPTION
50	43406	Label Professional
51	43413	Label Model no.505
52	43484	Washer 22.43 x 5.94
53	43719	Debris deflector spring
54	43790	Screw 5.5mm for plastic
55	44303	Height adjust handle
56	43910	Dust plug
57	43922	Handle grip
58	43941	Main body cover
59	43951	Round AV Rubber
60	43952	L.H. AV Mount
61	43953	R.H. AV Mount
62	43954	Main handle bracket
63	43955	Body AV Rubber
64	44086	Handle Throttle Assy. Complete
65	43961	LH Handle
66	44000	Engine Air Deflector
67	44164	Switch wire
68	44311	Main Body 205/505
69	43978	Main Shaft Screwed ends
70	43980	Flange bush spacer
71	43986	Manual 205
72	44003	Handle knob w/nut(44006+44075)
73	44010	Throttle cable
74	44012	Corrugated loom
75	44060	Handle Tube RH
76	44061	Handle Tube LH
77	44062	Handle cross brace
78	44064	Handle bolt hex piece
79	44085	Handle housing small
80	44074	Handle bolt 1/4"x6" BSW
81	43947	Komatsu-Zenoah G34L Engine
82	44312	Clutch drum cup 32mm L
83	43765	Wheel (only)
84	44309	Grass Flap
85	44001	Muffler Shield Plug
86	44310	Wheel Hub Cap
87	44305	Sealed Bearing 28x8x12.8
88	43860	Bearing 32x10x12+4mm
89	44016	Spacer 8.35mm
90	43963	RH Handle
91	44440	Switch




///ATOM MODEL 205 LAWN EDGER PARTS LIST

///ATOM

G34L

ENGINE PARTS IDENTIFICATION



Refer Page 19

///ATOM G34L ENGINE PARTS LIST

KEY #	PART #	DESCRIPTION	QTY	KEY #	PART #	DESCRIPTION	QTY
1	46600	Cylinder	1	60	46659	Knob	1
2	46601	Bolt, M5 x L20	4	61	46660	Plate, Stopper	1
3	46602	Gasket, Base	1	62	46661	Pulley	4
4	46603	Crankcase Comp.	1	63	46662	Screw, M6 x L14	1
5	46604	Pin	3	64	46663	Collar	1
6	46605	Gasket, Case	1	65	46664	Insulator	2
7	46606	Bearing	2	66	46665	Screw, M5 x L20	1
8	46607	Oil Seal	1	67	46666	Gasket, Insulator	1
9	46608	Oil Seal	1	68	46667	Gasket, Carburettor	1
10	46609	Bolt, M5 x L30	4	69	46668	Carburettor Assembly	1
11	46610	Snap Ring	1	70	46669	Body Assembly	1
12	46611	Piston	1	71	46670	Screen	1
13	46612	Ring	2	72	46671	Valve	1
14	46613	Pin	1	73	46672	Spring	1
15	46614	Ring	2	74	46673	Screw	1
16	46615	Bearing	1	75	46674	Pin	1
17	46616	Washer	2	76	46675	Lever	1
18	46617	Crankshaft Comp.	1	77	46676	Body, Purge	1
19	46618	Shoe, Clutch	2	78	46677	Cover, Pump	1
20	46619	Spring	1	79	46678	Pump, Priming	1
21	46620	Screw	2	80	46679	Diaphragm	1
22	46621	Washer	2	81	46680	Gasket, Diaphragm	1
23	46622	Washer	2	82	46681	Diaphragm, Pump	1
24	46623	Rotor	1	83	46682	Gasket, Pump	1
25	46624	Coil Assembly	1	84	46683	Jet	1
26	46625	Cord	1	85	46684	O-Ring	1
27	46626	Cap	1	86	46685	Ring	1
28	46627	Pin	2	87	46686	Swivel	1
29	46628	Grommet	1	88	46687	Valve Assembly	1
30	46629	Cap, Plug	1	89	46688	Screw	2
31	46630	Spring	1	90	46689	Bracket	1
32	46631	Bolt M4 x L22	2	91	46690	Nut, Adjuster	1
33	46632	Nut	1	92	46691	Screw, Adjuster	1
34	46633	Key	1	93	46692	Ring	1
35	46634	Muffler Assembly	1	94	46693	Screw	4
36	46635	Arrestor	1	95	46694	Washer	1
37	46636	Bolt, M5 x L60	2	96	46695	Screw, M5 x L50	2
38	46637	Bolt, M5 x L14	1	97	46696	Cleaner Assembly	1
39	46638	Gasket	1	98	46697	Cover	1
40	46639	Plate	1	99	46698	Filter	2
41	46640	Screw, M5 x L14	1	100	46699	Housing	1
42	46641	Cover	1	101	46700	Plate	1
43	46642	Bolt, M5 x L20	4	102	46701	Valve	1
44	46643	Plate	1	103	46702	Washer	1
45	46644	Cover	1	104	46703	Sleeve	2
46	46645	Screw, M5 x L12	4	105	46704	Screen	1
47	46646	Guard	1	107	46705	Tank Assembly	1
48	46647	Spark Plug	1	108	46706	Cap, Assembly	1
49	46648	Grommet	1	109	46707	Holder	1
50	46649	Cord	1	110	46708	Cap	1
51	46650	Cord, Earth	1	111	46709	Valve	1
52	46651	Clamp	1	112	46710	Packing	1
53	46652	Recoil Assembly	1	113	46711	Stopper	1
54	46653	Reel	1	114	46712	Pipe Clamp	1
55	46654	Screw	1	115	46713	Filter Assembly	1
56	46655	Spring, Spiral	1	116	46714	Clip	1
57	46656	Collar	1	117	46715	Screw, M5 x L22	4
58	46657	Arm	1	118	46716	Label	1
59	46658	Shroud Extension and Stand	1				